
VISTA-20

**2-PARTITIONED
SECURITY SYSTEM**

**PROGRAMMING
FORM**

® ADEMCO

Principal changes in this issue are indicated by margin lines.

Local programming requires the use of a 2-line Alpha keypad connected to partition 1 keypad terminals on the control.
 NOTE: For UL installations, the system may be configured as a single partition only.

Field Function **Programmed Values** [] = Default Value

SYSTEM SETUP (*20-*30)

*20	INSTALLER CODE	Enter 4 digits, 0-9 [4 1 1 2]	<input type="text"/>	<input type="text"/>
*21	QUICK ARM ENABLE	[0 = no]; 1 = yes	Partition 1 † <input type="checkbox"/>	Partition 2 † <input type="checkbox"/>
*22	RF SYSTEM	[0 = none]; 1 = 5800 (5881/5882)	<input type="checkbox"/>	<input type="checkbox"/>
*23	FORCED BYPASS	[0 = none]; 1 = bypass open zones "0". for UL installations.	Partition 1 † <input type="checkbox"/>	Partition 2 † <input type="checkbox"/>
*24	RF HOUSE ID CODE	[0][0] Enter 01-31 if using 5827 keypad. Part'n 2 RF House Code = Entered (Part'n 1) Code + 1	<input type="text"/>	<input type="text"/>
*25	WIRED ZONE EXPANSION	[0 = none]; 1 = 4219; 2 = 4229; 3 = 4204	<input type="text"/>	† <input type="checkbox"/>
*27	X-10 HOUSE CODE	[0 = A]; 1 = B, 2 = C, 3 = D, 4 = E, 5 = F, 6 = G, 7 = H, 8 = I, 9 = J, #10 = K, #11 = L, #12 = M, #13 = N, #14 = O, #15 = P	<input type="text"/>	<input type="text"/>
28	VOICE MODULE ACCESS CODE (4285)	(Partition 1 only) 1st digit: enter 1-9; 2nd digit: enter # + 11 for "", or # + 12 for "#". Default = 00 (no Voice Module).	<input type="text"/>	<input type="text"/>
*29	OUTPUT TO LONG RANGE RADIO	To enable, enter Trouble code 1-9, B (# + 11), C (# + 12), D (# + 13), E (# + 14), or F (# + 15). The 2nd digit of Trouble Dialer Report is automatically entered from field *60. "0" for UL installations.	<input type="text"/>	<input type="text"/>
*30	KEYSWITCH ENABLE (ZONE 7)	Enter 1 to enable, [0 to disable].	<input type="checkbox"/>	<input type="checkbox"/>

ZONE SOUNDS AND TIMING (*32-*38)

*32	SINGLE ALARM SOUNDING/ZONE	1 = yes; [0 = no]. "0" for UL installations.	<input type="checkbox"/>	† <input type="checkbox"/>
*33	FIRE SOUNDER TIMEOUT	[0 = timeout]; 1 = no timeout.	<input type="checkbox"/>	† <input type="checkbox"/>
*34	ALARM BELL TIMEOUT	0 = none; [1=4 min]; 2=8 min; 3=12 min. "1" (4 min.) minimum for UL.	<input type="checkbox"/>	† <input type="checkbox"/>
*35	ZONE TYPE 01 ENTRY DELAY	0 = 0, 1=20 secs, [2=30 secs], 3=45 secs, 4=60 secs; 5=90 secs. "1" max. for UL installations. Zone Type 02 Entry Delay = Zone Type 01 Delay + 30 secs. Exit Delay = Zone Type 01 Entry Delay + 40 secs.	Partition 1 † <input type="checkbox"/>	Partition 2 † <input type="checkbox"/>
*36	AUDIBLE EXIT WARNING	0 = no; [1 = yes].	Partition 1 † <input type="checkbox"/>	Partition 2 † <input type="checkbox"/>
*37	CONFIRMATION OF ARMING DING	[0 = no]; 1 = yes.	Partition 1 † <input type="checkbox"/>	Partition 2 † <input type="checkbox"/>
*38	POWER UP IN PREVIOUS STATE	0 = no; [1 = yes]. "1". for UL installations.	<input type="checkbox"/>	† <input type="checkbox"/>

DIALER PROGRAMMING (*40-*53)

In fields *40, *41, *42, enter up to the number of digits shown. Do not fill unused spaces. Enter 0-9; #+11 for '*'; #+12 for '#'; #+13 for a pause.

*40	PABX ACCESS CODE	Enter 4 digits. If fewer than 4 digits are entered, exit by pressing * (and press 41, if entering next field). To clear entries from field, press *40*.	<input type="text"/>
*41	PRIMARY PHONE No.	Enter up to 12 digits.	<input type="text"/>
*42	SECONDARY PHONE No.	Enter up to 12 digits.	<input type="text"/>
*43	PRIMARY SUBS ACCT # (PART'N 1)	PRIMARY RECEIVER <input type="text"/>	SECONDARY RECEIVER <input type="text"/>
*44	SECONDARY SUBS ACCT # (PART'N 1)	PRIMARY RECEIVER <input type="text"/>	SECONDARY RECEIVER <input type="text"/>
*45	PRIMARY SUBS ACCT # (PART'N 2)	PRIMARY RECEIVER <input type="text"/>	SECONDARY RECEIVER <input type="text"/>
*46	SECONDARY SUBS ACCT # (PART'N 2)	PRIMARY RECEIVER <input type="text"/>	SECONDARY RECEIVER <input type="text"/>

† Entry of a number other than one specified will give unpredictable results.

Do not fill unused spaces. If fewer than 12 digits entered, exit by pressing * (and press 42, if entering next field). To clear entries from field, press *41*.
 Do not fill unused spaces. If fewer than 12 digits entered, exit by pressing * (and press 43, if entering next field). To clear entries from field, press *42*.
 Enter 0-9; #+11 for B; #+12 for C; #+13 for D; #+14 for E; [#+15 for F].
 Enter * as 4th digit, if 3+1 dialer reporting is to be used. If only 3 digits used, exit by pressing * (and press next field).
 To clear entries from field, press *43*, *44*, *45*, or *46*.

Examples: For Acct No. 1234, enter:

For Acct No. B234, enter:

For Acct No. 123, enter:

- *47 PHONE SYSTEM SELECT If Cent. Sta. IS NOT on a WATS line: [0 = Pulse Dial]; 1 = Tone Dial †
 If Cent. Sta. IS on a WATS line: 2 = Pulse Dial ; 3 = Tone Dial.
- *48 REPORT FORMAT, PRIMARY/SECONDARY Primary Secondary
 [0 = 3+1, 4+1 ADEMCO L/S STANDARD] 6 or undefined = 4+2 ADEMCO EXPRESS
 1 = 3+1, 4+1 RADIONICS STANDARD 7 = ADEMCO CONTACT ID REPORTING
 2 = 4+2 ADEMCO L/S STANDARD 8 = 3+1, 4+1 ADEMCO L/S EXPANDED
 3 = 4+2 RADIONICS STANDARD 9 = 3+1, 4+1 RADIONICS EXPANDED
- *49 SPLIT/DUAL REPORTING [0 = Disable (Backup report only)]
TO PRIMARY **TO SECONDARY**
 1 = Alarms, Restore, Cancel Others
 2 = All except Open/Close, Test Open/Close, Test
 3 = Alarms, Restore, Cancel All
 4 = All except Open/Close, Test All
 5 = All All
- *50 15 SEC DIALER DELAY (BURG) [0 = no]; 1 = yes. "0" for UL installations. †
- *51 PERIODIC TEST REPORT [0 = none]; 1 = 24 hours; 2 = weekly; 3 = 30 days. †
 (Enter Test Code in field *64. Reports with Partition 1 subscriber No.)
- *52 TEST REPORT OFFSET 0 = 24 hour; 1 = 6 hours; [2 = 12 hours]; 3 = 18 hours. †
 (Time to 1st report from programming or downloading).
- *53 SESCOA/RADIONICS SELECT [0 = Radionics (0-9, B-F reporting)]; 1 = SESCOA (0-9 only reporting)
 Select 0 for all other formats.

† Entry of a number other than one specified will give unpredictable results.

*56 ZONE ASSIGNMENT/ALARM REPORT CODES —This field is an interactive mode. Fill in the required data on the worksheet below (and on next page) and follow the programming procedure in the installation manual.

ZONES ON CONTROL:

See explanation of headings on next page ➔

ZONE DESCRIPTION	ZONE No. (Zn)	ZONE TYPE (ZT)	PART'N No. (P)	ALARM RPT CODE (Hex) (RC)	INPUT TYPE (In)	RESPONSE TIME (RT)
Wired Zone 1*	0 1				HW	
Wired Zone 2	0 2				HW	
Wired Zone 3	0 3				HW	
Wired Zone 4	0 4				HW	
Wired Zone 5	0 5				HW	
Wired Zone 6	0 6				HW	
Wired Zone 7 ‡	0 7	‡			HW	
Wired Zone 8**	0 8				HW	
Expansion Module Supervision	0 9	0 5	Both		—	—
Duress	9 2	— —	Both		—	—
Console Panic (1 & *, or A)	9 5		Both		—	—
Console Panic (3 & #, or C)	9 6		Both		—	—
Console Panic (* & #, or B)	9 9		Both		—	—

*Zone 1 can be used as a 2-wire Fire zone. **Zone 8 can be used as a Glassbreak zone.
 ‡Zone 7 can be used for optional Keyswitch; shows as 77 for Zone Type (ZT).

EXPANSION ZONES:

Assign Zone Numbers (Zn) 10-17 to 4219/4229 Auxiliary Wired Loops A-H, if used.
 RF can use (Zn) 10-63 if 4219/4229 IS NOT used, (Zn) 18-63 if 4219/4229 IS used

ZONE DESCRIPTION	ZONE No. (Zn)	ZONE TYPE (ZT)	PART'N No. (P)	ALARM RPT CODE (Hex) (RC)	INPUT TYPE (In)	ENTER FOR RF ONLY LEARNED RF INPUT (L)
4219/4229 Loop A, 1st Exp'n Zone						
B, 2nd						
C, 3rd						
D, 4th						
E, 5th						

ZONE DESCRIPTION	ZONE No. (Zn)	ZONE TYPE (ZT)	PART'N No. (P)	ALARM RPT CODE (Hex) (RC)	ENTER FOR RF ONLY	
					INPUT TYPE (In)	LEARNED RF INPUT (L)
4219/4229 Loop F, 6th Exp'n Zone	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
G, 7th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
H, 8th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
9th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
10th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
11th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
12th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
13th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
14th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
15th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
16th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
17th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
18th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
19th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
20th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
21st	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
22nd	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
23rd	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
24th	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

EXPLANATION OF ZONE ASSIGNMENT TABLE HEADINGS

Zn = ZONE No. Zone Nos. are from 01 to 63, 92, 95, 96, 99. Some are pre-assigned.
 With Field *25 set for auxiliary wired loops (4219, or 4229), use Zone Nos. 10-17 for loops A-H.
 With Field *22 set for RF (5800), use Zone Nos. 18-63 if 4219/4229 is ALSO used, or 10-63 if 4219/4229 is NOT used.

ZT = ZONE TYPE 00 = Not Used 05 = Trouble Day/Alarm Night 20 = Arm-Stay
 01 = Entry/Exit #1 06 = 24 Hr Silent 21 = Arm-Away
 02 = Entry/Exit #2 07 = 24 Hr Audible 22 = Disarm
 03 = Perimeter 08 = 24 Hr Aux 23 = No Alarm Response
 04 = Interior Follower 09 = Fire 24 = Silent Burglary
 10 = Interior w/Delay

DEFAULT VALUES				
Zn:	01	02	03	04
ZT:	[09]	[01]	[03]	[03]
Zn:	05	06	07	08 99
ZT:	[03]	[03]	[03]	[03] [06]

P = PARTITION No. 1 or 2 Default Values for zones 01 - 08 = [1].

RC = ALARM REPORT CODE Two Hex Digits. For each Hex Digit, enter: 00-09 for 0-9, 10 for A, 11 for B, 12 for C, 13 for D, 14 for E, 15 for F. If "00" is entered as the first digit, there will be no report for that zone.
 For contact ID reporting, this is enabling code only. Enter any hex digit (other than 00) in the first pair of boxes. The second pair of boxes is ignored.

In = LOOP INPUT TYPE HW: Hard Wire Enter 3 for RF: Supervised RF
 AW: Aux Wire (4219 or 4229) Enter 4 for UR: Unsupervised RF
 Enter 5 for BR: Button Type RF

These are automatically assigned, except for RF zones.

RT = RESPONSE TIME 0 = 10msec; 1 = 350 msec; 2 = 700 msec. Default Values for zones 01 - 08 = 1 (350 msec)

L = LEARNED RF INPUT Used with 5800 RF Loop Input Devices. Record transmitter input number.

TO PROGRAM SYSTEM STATUS, & RESTORE REPORT CODES (*59-76, & *89):

With a 3+1 or 4+1 Standard Format: Enter a code in the *first* box: 1-9, 0, B, C, D, E, or F. Enter "#+10" for 0, "#+11" for B, "#+12" for C, "#+13" for D, "#+14" for E, "#+15" for F.

A "0" (not "#+10") in the *first* box will disable a report.

A "0" (not "#+10") in the *second* box will result in automatic advance to the next field when programming.

With an Expanded or 4+2 Format: Enter codes in *both* boxes (1st and 2nd digits) for 1-9, 0, or B-F, as described above.

A "0" (not "#+10") in the *second* box will eliminate the expanded message for that report.

A "0" (not "#+10") in *both* boxes will disable the report.

With Ademco Contact ID Reporting: Enter any digit (other than "0") in the *first* box, to enable zone to report (entries in the *second* boxes will be ignored).

A "0" (not "#+10") in the *first* box will disable the report.

Examples:

For Code 3 (single digit), enter:

For Code 32 (two digits), enter:

For Code B2 (Hexadecimal), enter:

SYSTEM STATUS REPORT CODES (*59-*68)

*59 EXIT ERROR REPORT CODE

*60 TROUBLE REPORT CODE

*61 BYPASS REPORT CODE

*62 AC LOSS REPORT CODE ▼

*63 LOW BAT REPORT CODE ▼

*64 TEST REPORT CODE

*65 OPEN REPORT CODE Part. 1 ††

Part. 2 ††

*66 ARM AWAY/STAY RPT CODE Part. 1 ††

AWAY STAY

Part. 2 ††

AWAY STAY

† 2nd digit is automatically sent as the 2nd digit of the zone alarm report code programmed in *56, if expanded or 4+2 reporting is selected.

†† 2nd digit is automatically sent as the user number if expanded or 4+2 reporting is selected.

*67 RF XMTR LOW BAT REPORT CODE

*68 CANCEL REPORT CODE

RESTORE REPORT CODES (*70-76)

*70 ALARM RESTORE RPT CODE

2nd digit is automatically sent as the 2nd digit of the zone alarm report code programmed in *56, if expanded or 4+2 reporting is selected.

*71 TROUBLE RESTORE RPT CODE

*72 BYPASS RESTORE RPT CODE

*73 AC RESTORE RPT CODE ▼

*74 LOW BAT RESTORE RPT CODE ▼

▼ Reports with Partition 1 Subscriber No.

*75 RF XMTR LO BAT RST RPT CODE

*76 TEST RESTORE RPT CODE

OUTPUT AND SYSTEM SETUP (*80-93)

*80 OUTPUT RELAYS AND POWERLINE CARRIER DEVICES	<i>Program only if Relays and/or Powerline Carrier devices are to be used. See next page.</i>
*81 ZONE LISTS FOR OUTPUT DEVICES	

*82 CUSTOM ALPHA EDITING: (Also entered from field *56): See procedure in instructions.

*83 ADD/DELETE RF INPUT IDs (Also entered from field *56): See procedure in instructions.

*89 EVENT LOG 80% FULL RPT CODE

*90 EVENT LOGGING

0 = None; 1 = Alarm/Alarm Restore; 2 = Trouble/Trouble Restore; 4 = Bypass/Bypass Restore; 8 = Open/Close.

Example: To select "Alarm/Alarm Restore", and "Open/Close", enter 9 (1 + 8); To select all, enter #15. Default = "3".

Note: System messages are logged when any non-zero selection is made.

*91 OPTION SELECTION [0 = None]; 4 = AAV
"0" for UL installations.

*92 PHONE LINE MONITOR ENABLE

[0 = Not used]

1 = Keypad display when line is faulted

2 = Keypad display plus keypad trouble sound

3 = Same as "2", plus Device #2 STARTS. If either partition is armed, external sounder activates also.

Note: Device #2 must either be programmed to be STOPPED in field *80 or STOPPED by Code + # + 8 + 2.

*93 NUMBER OF REPORTS IN ARMED PERIOD

[0 = 10 Alarm/Alarm Restore Reports]; 1 = Unlimited.

"1" for UL installations.

DOWNLOAD INFORMATION (*94,*95)

*94 DOWNLOAD PHONE No.

Enter up to 12 digits, 0-9; #+11 for '*'; #+12 for '#'; #+13 for a pause. Do not fill unused spaces. If fewer than 12 digits entered, exit field by pressing * (and press 95, if entering next field). To clear entries from field, press *94*.

Note: In UL installations, down loading may only be performed if a technician is at the site.

*95 RING DET COUNT FOR DOWNLOADING

[0 = Disable Station Initiated Download]; 1-14 = number of rings (1-9, # +10 =10, # +11 =11, # +12 =12, # +13 =13, # +14 =14); 15 = answering machine defeat (# +15 =15)

Note: Do not enter "0" if using 4285 Voice Module.

*96 INITIALIZES DOWNLOAD ID, SUBSCRIBER ACCOUNT No. FOR INITIAL DOWNLOAD: No data entry required.

*97 SETS ALL PROGRAM FIELDS TO DEFAULT VALUES: No data entry required.

*98 and *99 USED TO EXIT PROGRAM MODE (see page "7")

OUTPUT RELAYS/POWERLINE CARRIER DEVICES WORKSHEET FOR *80, and *81.

Applicable only if Relays and/or Powerline Carrier Devices are to be used.

***80 OUTPUT DEVICES** – This is an interactive menu mode. Fill in the required data on the worksheet on below and follow the programming procedure in the installation manual as you enter the data during the displays and prompts that appear in sequence.

- Notes:**
1. For Relays, field *25 must be programmed for a 4229 (Relays 01 and 02), OR for a 4204 (Relays 01 to 04).
 2. For Powerline Carrier devices, field *27 must be programmed with a House Code.
 3. Tamper of contacts or expansion units cannot be used to operate devices.

DEVICE NUMBER	X-10 SELECT	ACTION (A)	START ← either or both →				STOP ← either or both →		
			EVENT (EV)	ZONE LIST (ZL)	ZONE TYPE (ZT)	PART'N No. (P)	RESTORE of ZONE LIST (ZL)	ZONE TYPE /SYST OP'N (ZT)	PART'N No. (P)
OUTPUT RELAY OR P.L.C.D.* 01	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
OUTPUT RELAY OR P.L.C.D.* 02	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
OUTPUT RELAY OR P.L.C.D.* 03	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
OUTPUT RELAY OR P.L.C.D.* 04	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
P.L.C.D.* 05	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
P.L.C.D.* 06	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
P.L.C.D.* 07	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
P.L.C.D.* 08	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

↑ * P.L.C.D. = Powerline Carrier Device (X-10).

Where:

X-10 SELECT = Powerline Carrier Device Enter "1" if Powerline Carrier Device is being used, enter "0" if relay is being used.

A = DEVICE ACTION 0 = No Response; 1 = Close for 2 sec; 2 = Close and stay closed; 3 = Pulse on and off.

EV = EVENT 0 = Not used; 1 = Alarm; 2 = Fault; 3 = Trouble.

ZL = ZONE LIST 1, 2, or 3 (from Field *81) or 0 = Not Used.

"START" ZONE LIST: Upon alarm, fault, or trouble of ANY zone on this list, device action will START.

"STOP" RESTORE of ZONE LIST: Upon restore of ALL zones on this list, device action will STOP. It need not be same list as used for START.

ZT = ZONE TYPE/SYSTEM OPERATION

Choices for Zone Types are:

- | | |
|------------------------------|-----------------------|
| 00 = Not Used | 06 = 24 Hr Silent |
| 01 = Entry/Exit#1 | 07 = 24 Hr Audible |
| 02 = Entry/Exit#2 | 08 = 24 Hr Aux |
| 03 = Perimeter | 09 = Fire Trouble |
| 04 = Interior Follower | 10 = Interior w/Delay |
| 05 = Trouble Day/Alarm Night | 24 = Silent Burglary |

Note: Any zone in "ZT" going into alarm, fault, or trouble will actuate relay. Any zone of that type that restores will stop relay action.

Choices for System Operation are:

- | | | |
|-----------------------------|----------------------------|--------------|
| 20 = Arming-Stay | 38 = Chime | 52 = Kissoff |
| 21 = Arming-Away | 39 = Any Fire Alarm | 58 = Duress |
| 22 = Disarming (Code + OFF) | 40 = Bypassing | |
| 31 = End of Exit Time | 41 = **AC Power Failure | |
| 32 = Start of Entry Time | 42 = **System Battery Low | |
| 33 = Any Burglary Alarm | 43 = Communication Failure | |
| 36 = **At Bell Timeout*** | | |

Note: In normal operation mode:
Code + # + 7 + N Key Entry **starts** Device N.
Code + # + 8 + N Key Entry **stops** Device N.

** Use 0 (Any) for Partition No. (P) entry.

*** Or at Disarming, whichever occurs earlier.

P = PARTITION No. 1, 2, or 0 for Any

***81 ZONE LISTS FOR OUTPUT DEVICES** – This is an interactive mode. Fill in the required data on the worksheet below and follow the procedure in the installation manual as you enter the data during the displays and prompts that appear in sequence.

Note: Record desired zone numbers below. More or fewer boxes than shown may be needed, since any list may include *any* or *all* of system's zone numbers.

Zone List 1: Started or stopped by zone numbers (enter 00 to end entries).

□□, □□, □□, □□, □□, □□, □□, □□, □□, □□.etc.

Zone List 2: Started or stopped by zone numbers (enter 00 to end entries).

□□, □□, □□, □□, □□, □□, □□, □□, □□, □□.etc.

Zone List 3: Started or stopped by zone numbers (enter 00 to end entries).

□□, □□, □□, □□, □□, □□, □□, □□, □□, □□.etc.

SPECIAL MESSAGES

OC = OPEN CIRCUIT (no communication between Console and Control).

EE or **ENTRY ERROR** = ERROR (invalid field number entered; re-enter valid field number).

After powering up, **AC, dl** (disabled) or **System Busy** and **NOT READY** will be displayed after approximately 4 seconds. This will revert to **READY** in appx. 1 minute, which allows PIRS, etc. to stabilize. To bypass this delay, press: [#] + [0].

If **E4** or **E8** appears, more zones than the expansion units can handle have been programmed. Correct the programming and then completely de-power and re-power the control to clear this indication and remove the disable indication.

TO ENTER PROGRAMMING MODE:

1. POWER UP, then depress [*] and [#] both at once, within 50 seconds of powering up.
OR
2. Initially, key: **Installer Code (4 + 1 + 1 + 2)** plus **8 + 0 + 0**.
OR
3. If different **Installer Code** is programmed, key: **New Installer Code + 8 + 0 + 0**.
(if *98 was used to exit previously, method 1 above must be used to enter the program mode again)

TO EXIT PROGRAMMING MODE:

- *98 Exits programming mode and *prevents* re-entry by: **Installer Code + 8 + 0 + 0**. If *98 is used to exit programming mode, system must be powered down, and method 1 above used to enter the programming mode.
- *99 Exits programming mode and *allows* re-entry by: **Installer Code + 8 + 0 + 0** or: **Power-up, then press "*" and "#"** within 50 seconds of power up.



ALARM DEVICE MANUFACTURING CO.
A DIVISION OF PITTMWAY CORPORATION

165 Eileen Way, Syosset, New York 11791

Copyright © 1995 PITTMWAY CORPORATION